# VGN-B90PS VGN-B100/B100B/B150FP VGN-B1VP/B1XP/B3VP/B3XP VGN-B55C/B55G/B55L/B55S/B55T/B88C/B88GP/B88L


# **SERVICE MANUAL**

Ver 5-2005D

**Revision History** 

| Area         | Model                   | Lineup     |               |  |  |  |
|--------------|-------------------------|------------|---------------|--|--|--|
| Japanese     | Japanese                | VGN-B90PS* | 1             |  |  |  |
|              | LIC/Connedien           | VGN-B100B* | ]             |  |  |  |
| American     | US/Canadian             | VGN-B100*  |               |  |  |  |
|              | Latin                   | VGN-B150FP | <u></u> (MA)  |  |  |  |
|              |                         | VGN-B1XP   |               |  |  |  |
|              | A E D // 1/2            | VGN-B1VP   |               |  |  |  |
| European     | AEP/UK                  | VGN-B3XP   | <u></u> [MA]  |  |  |  |
|              |                         | VGN-B3VP   | <u></u> ♠[MA] |  |  |  |
|              | International VGN-B88GP |            | <u></u> (MA)  |  |  |  |
|              | IIILEITIALIOTIAI        | VGN-B55G   | <u></u> (MA)  |  |  |  |
| Asian/       |                         | VGN-B88L   | <u></u> [MA]  |  |  |  |
| Oceania/     | Korean                  | VGN-B55L   | <u></u> (MA)  |  |  |  |
| South Africa | Oleiman                 | VGN-B88C   | <u></u> [MA]  |  |  |  |
|              | Chinese                 | VGN-B55C   | <u></u> [MA]  |  |  |  |
|              | Taiwan                  | VGN-B55T   | <u></u> (MA)  |  |  |  |
|              | Thai                    | VGN-B55S   | <u></u> (MA)  |  |  |  |













- Design and specifications are subject to change without notice.
- 本機の仕様および外観は、改良のため予告なく 変更することがありますが、ご了承ください。

PERSONAL COMPUTER



# Information in this document is subject to change without notice.

Sony, VAIO and CLIE are trademarks or registered trademarks of Sony. Microsoft, Windows, Windows Media, Outlook, Bookshelf and other Microsoft products are trademarks or registered trademarks of Microsoft Corporation in the United State and other countries.

The word Bluetooth and the Bluetooth logo are trademarks of Bluetooth SIG, Inc. AMD, the AMD logo, other AMD product names and combinations thereof are trademarks of Advanced Micro Devices, Inc. Intel Inside logo, Pentium and Celeron are trademarks or registered trademarks of Intel Corparation. Transmeta, the Transmeta logo, Crusoe Processor, the Crusoe logo and combinations thereof are trademarks of Transmeta Corporation in the USA and other countries.

Graffiti, Hotsync, PalmModem, and Palm OS are registered trademarks, and the Hotsync logo and Palm are trademarks of Palm, Inc. or its sub sidiaries. (M) and Motrola are trademarks of Motrola, Inc. Other Motrola pruducts and services with (R) mark like Dragomball are the trademarks of Motrola, Inc.

All other name of systems, products and services in this manual are trademarks or registered trademarks of their respective owners.

In this manual, the (TM) or (R) mark are not specified.

<u>Caution Markings for Lithium/Ion Battery</u> - The following or similar texts shall be provided on battery pack of equipment or in both the operating and the service instructions.

CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufactureris instructions.

CAUTION: The battery pack used in this device may present a fire or chemical burn hazard if mistreated. Do not disassemble, heat above  $100 \infty C$  ( $212 \infty F$ ) or incinerate.

Dispose of used battery promptly. Keep away from children.

CAUTION: Changing the back up battery.

- i Overcharging, short circuiting, reverse charging, multilation or incineration of the cells must be avoided to prevent one or more of the following occurrence; release of toxic materials, release of hydrogen and/or oxygen gas, rise in surface temperature.
- ï If a cell has leaked or vented, it should be replaced immediately while avoiding to touch it without any rotection.

### **Service and Inspection Precautions**

# 1. Obey precautionary markings and instructions

Labels and stamps on the cabinet, chassis, and components identify areas requiring special precautions. Be sure to observe these precautions, as well as all precautions listed in the operating manual and other associated documents.

#### 2. Use designated parts only

The setis components possess important safety characteristics, such as noncombustibility and the ability to tolerate large voltages. Be sure that replacement parts possess the same safety characteristics as the originals. Also remember that the  $\triangle$  mark, which appears in circuit diagrams and parts lists, denotes components that have particularly important safety functions; be extra sure to use only the designated components.

# 3. Always follow the original design when mounting parts and routing wires

The original layout includes various safety features, such as inclusion of insulating materials (tubes and tape) and the mounting of parts above the printer board. In addition, internal wiring has been routed and clamped so as to keep it away from hot or high-voltage parts. When mounting parts or routing wires, therefore, be sure to duplicate the original layout.

#### 4. Inspect after completing service

After servicing, inspect to make sure that all screws, components, and wiring have been returned to their original condition. Also check the area around the repair location to ensure that repair work has caused no damage, and confirm safety.

#### 5. When replacing chip components...

Never reuse components. Also remember that the negative side of tantalum capacitors is easily damaged by heat.

#### 6. When handling flexible print boards...

- ï The temperature of the soldering-iron tip should be about 270∞C.
- ï Do not apply the tip more than three times to the same pattern.
- ï Handle patterns with care; never apply force.

Caution: Remember that hard disk drives are easily damaged by vibration. Always handle with care.

# ATTETION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFÉS PAR UNE MARQUE A SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈSES SONY DONT LES NUMÉROS SONT DONNÉSDANS CE MANUEL OU DANS LES SUPPÉMENTS PUBLIÉS PAR SONY.

Confidential

VGN-B90PS (J)

VGN-B100/B100B/B150FP (AM)

VGN-B1VP/B1XP/B3VP/B3XP (EU)

### **TABLE OF CONTENTS**

| <u>Section</u>     | <u>Title</u>                  | Page      |
|--------------------|-------------------------------|-----------|
|                    | SPECIFICATIONS                |           |
| 1-1. Specification | ns                            | 1-1       |
| 1-2. CTO Inform    | ation                         | 1-2       |
|                    |                               | (to 1-2)  |
| CHAPTER 2.         | BLOCK DIAGRAM                 | 2-1       |
|                    |                               | (to 2-1)  |
| CHAPTER 3.         | FRAME HARNESS DIAGRAM         | 3-1       |
|                    |                               | (to 3-1)  |
| CHAPTER 4.         | EXPLODED VIEWS AND PARTS LIST |           |
| Palmrest           |                               |           |
| P-1                |                               | 4-2       |
| Main Board         |                               |           |
| M-1                |                               | 4-4       |
| Bottom             |                               |           |
| B-1                |                               | 4-6       |
| LCD                |                               |           |
| L-1. 14.1 SX       | GA+ (To)                      | 4-8       |
| L-2. 14.1 XG       | A (Hi)                        | 4-10      |
| L-3. 14.1 XG       | A (CPT)                       | 4-12      |
| Accessories        |                               |           |
| A-1                |                               | 4-14      |
|                    |                               | (to 4-14) |
| CHAPTER 5.         | OTHERS                        |           |
| 5-1. The Barcode   | : Label                       | 5-1       |
| 5-1. Replacing th  | ne CPU                        | 5-2       |
|                    |                               | (to 5-2)  |

History of the changes is shown as the "Revision History" at the end of this data.

変更履歴は、" Revision History " として、 本データ末に記載してあります。

## Confidential

VGN-B90PS (J) VGN-B100/B100B/B150FP (AM) VGN-B1VP/B1XP/B3VP/B3XP (EU)

# CHAPTER 1. SPECIFICATIONS

## 1-1. Specifications

|                        | J                    | AM                           |               |               | Е             | U                   |                     |
|------------------------|----------------------|------------------------------|---------------|---------------|---------------|---------------------|---------------------|
|                        | VGN-B90PS*           | VGN-B100B*, B100*            | VGN-B150FP    | VGN-B1XP      | VGN-B1VP      | VGN-B3XP            | VGN-B3VP            |
| CPU                    | PM 755,745,725,CM350 | PM 755,745,735,725,715,CM350 | PM715         | PM735         | PM725         | PM745               | PM725               |
| ChipSet                | 855GME               | 855GME                       | 855GME        | 855GME        | 855GME        | 855GME              | 855GME              |
| LCD                    | 14.1SXGA+, 14.1XGA   | 14.1SXGA+, 14.1XGA           | 14.1 XGA      | 14.1 SXGA+    | 14.1 XGA      | 14.1 SXGA+          | 14.1 XGA            |
| HDD                    | 80GB,60GB,40GB       | 100GB,80GB,60GB,40GB,30GB    | 40GB          | 60GB          | 40GB          | 80GB                | 60GB                |
| MEMORY(On board)       | 512MB, 256MB         | *1)                          | 512MB(DDR333) | 512MB(DDR333) | 512MB(DDR333) | 512MB(DDR333)       | 512MB(DDR333)       |
| MEMORY(Slot)           | - /512MB             | <u> </u>                     | -             | -             | -             |                     | -                   |
| QUANTITY[STANDARD/MAX] | /1536MB              | /1536MB                      | 512MB/1536MB  | 512MB/1GB     | 512MB/1GB     | 512MB/1.5GB         | 512MB/1.5GB         |
| OPT-DRIVE              | DVD+-RW,Combo(24)    | DVD+-RW,Combo(24),DVD-ROM    | Combo(24)     | DVD+-RW       | Combo(24)     | DVD+-RW/12.7/x8/+DL | DVD+-RW/12.7/x8/+DL |
| AC adaptor             | VGP-AC16V8           | VGP-AC16V8                   | VGP-AC16V8    | VGP-AC16V8    | VGP-AC16V8    | VGP-AC16V8          | VGP-AC16V8          |
| Battery                | PCGA-BP2V            | PCGA-BP2V                    | PCGA-BP2V     | PCGA-BP2V     | PCGA-BP2V     | PCGA-BP2V           | PCGA-BP2V           |
| Wireless-LAN           | 0                    | O/ X                         | 0             | 0             | 0             | 0                   | 0                   |
| Bluetooth              | ×                    | ×                            | ×             | ×             | ×             | X                   | X                   |
| OS                     | XP Pro               | XP Pro, XP Home              | XP Pro        | XP Pro        | XP Pro        | XP Pro              | XP Pro              |

<sup>\*1)512</sup>MB(On board)+1GB(slot) /512MB(On board)+512MB(slot) /512MB(On board)/256MB(On board)

⑤ [MA]

|                        |               |               |               | A             | 0             |               |               |               |
|------------------------|---------------|---------------|---------------|---------------|---------------|---------------|---------------|---------------|
|                        | VGN-B88GP     | VGN-B88L      | VGN-B55G      | VGN-B55S      | VGN-B55L      | VGN-B55T      | VGN-B88C      | VGN-B55C      |
| CPU                    | PM715         | PM715         | PM715         | PM715         | PM715         | PM715         | PM725         | CM350         |
| ChipSet                | 855GME        |
| LCD                    | 14.1 SXGA+    | 14.1 XGA      |
| HDD                    | 40GB          | 60GB          | 40GB          | 40GB          | 40GB          | 40GB          | 40GB          | 40GB          |
| MEMORY(On board)       | 512MB(DDR333) | 256MB(DDR333) |
| MEMORY(Slot)           | -             | -             | -             | -             | -             | -             | -             | -             |
| QUANTITY[STANDARD/MAX] | 512MB/1536MB  | 256MB/1280MB  |
| OPT-DRIVE              | DVD+-RW       | Combo(24)     |
| AC adaptor             | VGP-AC16V8    |
| Battery                | PCGA-BP2V     |
| Wireless-LAN           | 0             | 0             | 0             | 0             | 0             | 0             | 0             | 0             |
| Bluetooth              | ×             | ×             | ×             | ×             | ×             | ×             | ×             | ×             |
| OS                     | XP Pro        | XP Home       |
|                        | <u></u> [MA]  | <u></u> [MA]  | <u></u> (MA)  | <u></u> [MA]  | <u></u> (MA)  | <u></u> (MA)  | <u></u> [MA]  | <u></u> [MA]  |

<sup>•</sup> The trademarks or registered trademarks of above table, refer to page 2.

Confidential

/₄\ [MA]

VGN-B90PS (J)

VGN-B100/B100B/B150FP (AM)

VGN-B1VP/B1XP/B3VP/B3XP (EU)

/₄\ [MA]

<sup>•</sup> The model that is accompanied by astarisk (\*) is CTO model.

The parts to component for CTO models, refer to CTO Information.

<sup>・</sup>本表中の商標・登録商標については、2ページをご参照下さい。


<sup>・</sup>機種名に(\*)がつくのは、CTOモデルです。 組み合わせについては、CTO Informationをご参照ください。

### 1-2. CTO Information

### 1. VGN-B90PS (Japanese Area)

Model name:VGN-B90PS(Japanese Area) OS:Windows XP Pro

Ver.1.0



Confidential


VGN-B90PS (J)

VGN-B100/B100B/B150FP (AM)

VGN-B1VP/B1XP/B3VP/B3XP (EU)

### 2. VGN-B100B/B100 (American Area)


Model name:VGN-B100B Model Number:PCG-5B1L(With W-LAN),PCG-5B2L(Without W-LAN) OS:Windows XP Pro



#### Model name:VGN-B100

Model Number:PCG-5B1L(With W-LAN),PCG-5B2L(Without W-LAN)
OS:Windows XP Home

Ver.1.0




Confidential

VGN-B90PS (J)

VGN-B100/B100B/B150FP (AM) VGN-B1VP/B1XP/B3VP/B3XP (EU)

## CHAPTER 2. BLOCK DIAGRAM



Configurable devices

I/F connectors


Confidential

VGN-B90PS (J)

VGN-B100/B100B/B150FP (AM)

VGN-B1VP/B1XP/B3VP/B3XP (EU)

# CHAPTER 3. FRAME HARNESS DIAGRAM



## Confidential

VGN-B90PS (J)

VGN-B100/B100B/B150FP (AM)

VGN-B1VP/B1XP/B3VP/B3XP (EU)

## CHAPTER 4. **EXPLODED VIEWS AND PARTS LIST**

- The parts list is compiled by blocks of a palmrest and bottom etc. The sections of the parts list are different depending on the model. Please refer to list of ontents shown in the below.
- 分解図と部品表は、パームレスト、ボトムなどのブロックごとに 分かれています。機種によって部品表のセクションが異なりま すので、詳細は右下の一覧表を参照してください。

| Section              | Page |
|----------------------|------|
| Palmrest             |      |
| P-1                  | 4-2  |
| Main Board           |      |
| M-1                  | 4-4  |
| LCD                  |      |
| L-1. 14.1 SXGA+ (To) | 4-8  |
| L-2. 14.1 XGA (Hi)   | 4-10 |
| L-3. 14.1 XGA (CPT)  | 4-12 |
| Accessories          |      |
| A-1                  | 4-14 |

#### 【使用上の注意】

• Items marked " \* " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

NOTE:

- The mechanical parts with no reference number in the exploded views are not supplied.
- When two or more parts are shown, use the part described first as the main part.
- The parts marked "\$" are the High Value Modules (HVM).
- The parts marked "#" are the parts on which barcode label is attached.

For the barcode label, refer to CHAPTER 5.

- The parts marked " & " are the "Customer Replacable Parts (CRP)" that can be replaced by Field Customer Support. Especially the parts with the <&> mark require the special attention to use them. Here fore, check firstWhether the desired part is one of the targetted part the Customer Replaceable Parts(CRP), or the non-targetted parts by referring to the exploded view.
- Regarding the boards of this model, the discrete parts on the boards cannot be replaced. However, Some connectors can be replaced.
- The model that is accompanied by asterisk (\*) is the CTO model.

For the equipment configuration, refer to the CTO Information.

The components identified by Les composants identifiés par mark ∆ or dotted line with mark une marque∧ sont critiques A are critical for safety. Replace only with part number Ne les remplacer que par une specified.

pour la sécurité.


pièce portant le numéro spécifié.

- ・\*印の部品は常備在庫しておりません。
- ・図面番号のない部品は供給しません。
- ・併記部品の場合,上部記載部品をメイン部品として 使用してください。
- ・部品名称の前に\$印のついた部品は、High Value Module(HVM)です。
- ・部品名称の前に#印のついた部品は、バーコードラベル 貼付部品です。

バーコードラベルについてはCHAPTER 5を参照して ください。

- ・部品名称の前に&印のついた部品は、お客様窓口 などでも交換可能なCustomer Replacable Parts (CRP) です。
- 特に<&>印のついた部品は、使い分けが必要な部品 ですので、分解図でCoustomer Replacable Parts 対象部品か,対象外部品かを必ず御確認ください。
- ・本モデルの基板については、基板上の各部品の修理 は行うことができません。ただし、一部のコネクタ については,修理可能です。
- ・機種名に(\*)がつくのはCTOモデルです。 組み合わせについては,CTO Informationを 御確認ください。

▲ 印の部品, または ▲ 印付きの点線で囲まれた部品 は、安全性を維持するために重要な部品です。 従って 交換時は、必ず指定の部品を使用してください。



|              |    |        | Palmrest | Main Board | Bottom | LCD   | Accessoris |
|--------------|----|--------|----------|------------|--------|-------|------------|
|              | J  | B90PS* | P-1      | M-1        | B-1    | L-1,2 | A-1        |
|              |    | B100B* | P-1      | M-1        | B-1    | L-1,3 | A-1        |
|              | AM | B100*  | P-1      | M-1        | B-1    | L-1,3 | A-1        |
| <u></u> (MA) |    | B150FP | P-1      | M-1        | B-1    | L-3   | A-1        |
|              | EU | B1XP   | P-1      | M-1        | B-1    | L-1   | A-1        |
|              |    | B1VP   | P-1      | M-1        | B-1    | L-2   | A-1        |
| <u></u> [MA] |    | B3XP   | P-1      | M-1        | B-1    | L-1   | A-1        |
| <u></u> [MA] |    | B3VP   | P-1      | M-1        | B-1    | L-2   | A-1        |
| <u></u> (MA) |    | B88GP  | P-1      | M-1        | B-1    | L-1   | A-1        |
| <u></u> (MA) |    | B88L   | P-1      | M-1        | B-1    | L-3   | A-1        |
| <u></u> [MA] |    | B55G   | P-1      | M-1        | B-1    | L-3   | A-1        |
| <u></u> (MA) | AO | B55S   | P-1      | M-1        | B-1    | L-3   | A-1        |
| <u></u> [MA] | AU | B55L   | P-1      | M-1        | B-1    | L-3   | A-1        |
| <u></u> (MA) |    | B55T   | P-1      | M-1        | B-1    | L-3   | A-1        |
| <u></u> [MA] |    | B88C   | P-1      | M-1        | B-1    | L-2   | A-1        |
| <u></u> [MA] |    | B55C   | P-1      | M-1        | B-1    | L-2   | A-1        |


\*: CTO model

## Confidential

VGN-B90PS (J)

VGN-B100/B100B/B150FP (AM) VGN-B1VP/B1XP/B3VP/B3XP (EU)

P-1 P-1. Palmrest



Confidential

VGN-B90PS (J) VGN-B100/B100B/B150FP (AM) VGN-B1VP/B1XP/B3VP/B3XP (EU)

## P-1. Palmrest

| P-1 |
|-----|
|-----|

| Ref.No.  | Part No.                   | Description                 |                                      |
|----------|----------------------------|-----------------------------|--------------------------------------|
| 1        | 2-176-357-01               | HOLDER TOUCHPAD (HTA)       |                                      |
| 2        | 1-797-073-11               | TOUCH PAD                   |                                      |
| 3        | 1-829-803-11               | FLEXIBLE FLAT CABLE (8PIN)  |                                      |
| 4        | 1-829-804-11               | FLEXIBLE FLAT CABLE(12PIN)  |                                      |
| 5        | A-1090-581-A \$            | T/P SW BOARD(S)             |                                      |
| <u> </u> | [CHG] X-2050-121-1         |                             |                                      |
| 6 l      | L- <del>A-1090-607-A</del> | HOUSING PALMREST ASSY (HPA  | A)(S)                                |
| 7        | A-1090-580-A \$            | LED SW M/S BOARD(S)         |                                      |
| 8        | 1-962-037-11               | HARNESS (RJ11)              |                                      |
| 9        | A-1082-151-A #             | MDC                         |                                      |
| 10       | 1-829-805-11               | FLEXIBLE FLAT CABLE(40PIN)  |                                      |
| A        | [CHG] 2-176-364-11         |                             |                                      |
| 12       | — <del>A-1090-587-A</del>  | BRACKET SPK (HPA)(S)        |                                      |
| 13       | A-1082-147-A               | SPEAKER                     | - ^ FOLIO1 o 470 457 44              |
| 14       | A-1090-586-A               | TAPE ADHESIVE (SPK) (S)     | <b>-</b> <u>∧</u> [CHG] 2-178-157-11 |
| 16       | A-1090-583-A               | SHUTTER PCMCIA(HPA)(S)      | <b>-</b> ∕∑ [CHG] 2-176-342-11       |
| 17       | <del></del>                | SPRING PCMCIA(HPA)(S)       | 2/2/[0110] 2-1/0-042-11              |
| <u> </u> | [CHG] 2-176-343-11         |                             |                                      |
| 18       | 2-546-388-01               | SHEET KEYBOARD              |                                      |
| 20       | <del> A-1090-585-A</del>   | LATCH DETECTOR (HPA)(S)     |                                      |
| 21       | A-1090-876-A \$            | MOUNTED PWB IFX-369         |                                      |
| 22       | 1-829-802-11               | FLEXIBLE FLAT CABLE (50PIN) |                                      |
| 23       | 2-176-488-01               | STAND HDDMT (PALM)          |                                      |
| 2        | [CHG] 2-176-358-11         |                             |                                      |
| 24       | A-1090-582-A \$            | USB I.LINK BOARD(S)         |                                      |
| 25       | 1-829-799-11               | FLEXIBLE FLAT CABLE (18PIN) |                                      |
| 27       | 4-671-461-01               | TAPE (M)                    |                                      |
| 28       |                            | FILAMENT TAPE(12x30) (●1)   |                                      |
| 29       | 2-548-262-01               | SPACER PCC(PALM)            |                                      |
| <u> </u> | [CHG] 2-176-341-11         |                             |                                      |
| 31       | <del>A-1095-445-A</del>    | SPRING POW (HPA) (S)        |                                      |
| 32       |                            | KAPTON TAPE (●1)            | <b>-</b> <u>∕</u> [CHG] 2-176-339-11 |
| 33       | A-1095-443-A               | BUTTON POW(HPA)(S)          | - <u>/2</u> [CHG] 2-1/0-339-11       |
| 34       | A-1095-444-A               | ESCUTCHEON POW(HPA)(S)      | <b>-</b> ∕∑ [CHG] 2-176-340-11       |
| 35       | <del></del>                | COVER MODEM (HPA) (S)       | - /2\[0110]2 110 040 11              |
| 2        | [CHG] 2-176-338-11         |                             |                                      |
| B1       | 4-642-229-01               | TAPPING(B2x)                |                                      |
| B2       | 4-672-834-51               | SCREW,+B EG GRIP            |                                      |
| В3       | 4-672-834-21               | SCREW,+B EG GRIP            |                                      |
| B5       | 4-672-834-91               | SCREW,+B EG GRIP            |                                      |
| В6       | 4-671-885-11               | SCREW,TAPPING,SPECIAL       |                                      |
| B10      | 4-672-834-31               | SCREW, +B EG GRIP           |                                      |
| B21      | 4-673-751-01               | NUT (M2) (TYPE2)            |                                      |
| B22      | 4-651-989-01               | SPACER (MBX)                |                                      |
| -        |                            | , ,                         |                                      |

<sup>●1</sup> Use the FILAMENT TAPE

| <ul> <li>Use the KAPTON TAP.</li> </ul> | E |  |
|---|---|--|
|---|---|--|

|               |          |                              |                |                                       | J      |        | AM              | _                |              | U        |                | AO             |      |           |           |      |  |           |            |  |
|---------------|----------|------------------------------|----------------|---------------------------------------|--------|--------|-----------------|------------------|--------------|----------|----------------|----------------|------|-----------|-----------|------|--|-----------|------------|--|
|               | <u> </u> | [CHG] 2-176-36               | 3-11           |                                       | B90PS* | B100B* | B100*           | B150FP           | B1XP<br>B1VP | B3XP     | B3VP           | B88GP          | B88L | B55G      | B55S      | B55L | B55T   | B88C      | באכ        |  |
|               | Ref. No. | Part No.                     |                | Description                           |        |        |                 |                  |              |          |                |                |      |           |           |      |  |           |            |  |
|               | 11       | X-2023-015-1                 |                | ESCUTCHEON WLAN ASSY (EWA)            | ٠.     | •      | •               | •                | •            |          |                |                |      | _         | •         |      | •  | •         | 4          |  |
|               |          | X-2023-015-1<br>X-2023-016-1 |                | ESCUTCHEON WOWL ASSY (EWA)            |        | -      |                 | •                |              | -        | +              | •              | -    |           | •         | •    | -  |           | -          |  |
|               | 15       | 2-176-363-11                 |                | KNOB WLAN WL(S)                       | •      | •      | •               | •                | •            | •        | •              | •              | •    | •         | •         | •    | •  |           |            |  |
|               | 19       | 1-478-920-32                 | #              | KEYBOARD UNIT (CH)                    |        | •      | -               | -                | •            | _        | +              | -              | -    | _         | •         | •    | •  | -         | Ľ          |  |
|               | 19       |                              |                |                                       |        |        | <del>  -</del>  |                  |              |          | +              | <del> </del>   |      |           |           |      |  |           | <b>}</b>   |  |
|               |          | 1-478-920-22<br>1-478-920-62 | #<br>          | KEYBOARD UNIT (DE) KEYBOARD UNIT (ES) |        |        | <del>  -</del>  |                  |              |          | ╁              | <del> </del>   |      |           |           |      |  |           | <b>}</b>   |  |
|               |          |                              | <del>-</del> # |                                       |        |        |                 |                  |              |          | +              | <del> </del> - |      |           |           |      |  |           | <b>}</b>   |  |
|               |          | 1-478-920-42                 | #              | KEYBOARD UNIT (FR)                    |        |        |                 |                  |              |          | +              | <del> </del> - |      |           |           |      |  |           | <b>}</b>   |  |
|               |          | 1-478-920-12                 | #              | KEYBOARD UNIT (GB)                    |        |        | <del>  -</del>  |                  |              |          | +              | <del> </del>   |      |           |           |      |  |           | <b>}</b>   |  |
|               |          | 1-478-920-52                 | <del>-</del> # | KEYBOARD UNIT (IT)                    |        |        |                 |                  | ٠.,          |          | ┼              | <del> </del> - |      |           |           |      |  |           | <b>}</b>   |  |
|               |          | 1-478-919-12                 | #              | KEYBOARD UNIT (JP)                    |        |        |                 |                  |              |          | <del> </del>   | <del> </del> - |      |           |           |      |  |           | <b>}</b> - |  |
| <u>}</u> [MA] |          | 1-478-919-32                 | #              | KEYBOARD UNIT (KR)                    |        |        |                 |                  | •            |          | <del> </del> - | <del> </del> - | •    |           |           | •    |  |           | <b>}</b> - |  |
|               | ļ        | 1-478-920-92                 | #<br>          | KEYBOARD UNIT (PT)                    |        |        | <del>  </del> - |                  | • •          |          | +              | <del> </del> - |      |           |           |      |  |           | <b>}</b> - |  |
|               | ļ        | 1-478-920-82                 | #              | KEYBOARD UNIT (SE)                    |        |        | <del>  </del> - |                  | •            |          | •              | <del> </del> - |      |           |           |      |  |           | <b>}</b> - |  |
| ∑[MA]         | ļ        | 1-478-919-42                 | #              | KEYBOARD UNIT (TH)                    |        |        | ļ <u>-</u>      | +                |              |          | <del></del>    | ļ              | ļ    |           | •         |      |  |           | <b>}</b>   |  |
| [MA]          |          | 1-478-919-52                 | #              | KEYBOARD UNIT (TW)                    |        |        |                 |                  |              |          | <b></b>        | ļ              | ļ    |           |           | ļ    | •  |           | ļ          |  |
|               |          | 1-478-919-22                 | #              | KEYBOARD UNIT (US)                    |        | •      | •               |                  |              |          | <b></b>        | •              | ļ    | •         |           | ļ    |  | •         | •          |  |
| [MA]          |          | 1-478-920-72                 | #              | KEYBOARD UNIT(LA)                     |        |        | $\sqcup$        | •                |              |          | _              | _              |      |           |           |      |  | _         | $\vdash$   |  |
| ∑[MA]         | 26       | 2-345-283-11                 |                | ID LABEL                              |        |        | ļļ.             | •                |              |          | ļ              | ļ              | ļ    |           |           | ļ    |  |           | ļ          |  |
|               |          | 2-345-283-21                 |                | ID LABEL                              |        |        | ļļ.             |                  |              |          | ļ              | ļ              | ļ    |           |           | ļ    |  |           | ļ          |  |
|               |          | 2-345-283-31                 |                | ID LABEL                              |        |        | ļļ.             |                  | •            |          | ļ              | ļ              | ļ    |           |           | ļ    |  |           | ļ          |  |
|               |          | 2-345-283-41                 |                | ID LABEL                              |        |        | ļļ.             | -                | •            | <u>'</u> | ļ              | ļ              | ļ    |           |           |      |  |           | ļ          |  |
| ∑[MA]         |          | 2-348-528-01                 |                | ID LABEL (C)                          |        |        | ļļ.             | -                |              |          | ļ              | ļ              | ļ    |           |           |      |  | •         | ļ          |  |
| ∑[MA]         |          | 2-348-528-11                 |                | ID LABEL (C)                          |        |        | ļļ.             | -                |              |          | ļ              | ļ              | ļ    |           |           |      |  |           | •          |  |
| <u>}</u> [MA] |          | 2-345-331-01                 |                | ID LABEL (I)                          |        |        | ļļ.             |                  |              |          | ļ              | •              | ļ    |           |           | ļ    |  |           | Ļ.,        |  |
| <u>}</u> [MA] |          | 2-345-331-11                 |                | ID LABEL (I)                          |        |        | ļļ.             | -                |              |          | ļ              | ļ              | •    |           |           |      |  |           | ļ          |  |
| ∑[MA]         |          | 2-345-331-21                 |                | ID LABEL (I)                          |        |        | ļļ.             | -                |              |          | ļ              | ļ              | ļ    | •         |           |      |  |           | ļ          |  |
| <u>}</u> [MA] |          | 2-345-331-31                 |                | ID LABEL (I)                          |        | ļ      | ļļ.             | -                |              |          | ļ              | ļ              | ļ    |           | •         |      |  |           | <b> </b>   |  |
| <u>}</u> [MA] |          | 2-345-331-41                 |                | ID LABEL (I)                          |        | ļ      | ļļ.             | -                |              |          | ļ              | ļ              | ļ    |           |           | •    |  |           | ļ          |  |
| <u>}</u> [MA] |          | 2-345-331-51                 |                | ID LABEL (I)                          |        |        | ļļ.             |                  |              |          | ļ              | ļ              | ļ    |           |           | ļ    | •  |           | Ļ.,        |  |
|               |          | 2-320-032-01                 |                | ID LABEL (UCTO)                       |        |        | •               |                  | _            |          | ļ              | <u> </u>       |      |           |           |      |  |           | L.         |  |
|               |          | 2-320-032-11                 |                | ID LABEL (UCTO)                       |        | •      | ļļ.             |                  | _            |          | ļ              | <u> </u>       |      |           |           |      |  |           | L.,        |  |
| <u>}</u> [MA] |          | 2-629-064-01                 |                | LABEL ID                              |        | ļ      | ļļ.             |                  | _            | •        | +              | ļ              | ļ    |           | ļ         | ļ    | <u>                                     </u> |           | ļ          |  |
| <u>}</u> [MA] |          | 2-629-065-01                 |                | LABEL ID                              |        |        |                 |                  |              |          | •              |                |      |           |           |      |  |           | L          |  |
|               |          |                              |                |                                       |        |        | _               | <u></u> §<br>May |              | 4        |                |                | ß    | <u> 3</u> | <u> 3</u> |      | <u> </u>                                     | $\Lambda$ | 2          |  |
|               |          |                              |                |                                       |        |        |                 | _                |              | [MA]     | [MA]           | [MA]           | [MA] | [MA]      |           | [MA] | [MA]   | _         | 1000       |  |

This parts list contains two different types of parts.
 The first type is the parts that are common to all models.
 The other type is the parts that are different depending on each model.

- The parts of Ref.15 is used in the Wireless-LAN installation models.
- ・この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- Ref. 15は、ワイヤレスラン搭載モデル用の部品です。


Confidential

VGN-B90PS (J)

VGN-B100/B100B/B150FP (AM)

VGN-B1VP/B1XP/B3VP/B3XP (EU)

#### M-1. Main Board M-1



Confidential

VGN-B90PS (J) VGN-B100/B100B/B150FP (AM) VGN-B1VP/B1XP/B3VP/B3XP (EU)

## M-1. Main Board

| Ref.No.<br>28<br>301<br>303<br>304 |              | Description FILAMENT TAPE(12x30) (●1) PCCARD CONNECTOR FRAME INSULATOR PRCON (MB) BRACKET PCMCIA(MB) |
|------------------------------------|--------------|--|
| 308                                | 2-176-465-01 | PLATE MEMO (MB)  |
| 309                                | 2-176-471-01 | SHEET THERMAL (MEMO)   |
| 310                                | 1-787-244-11 | FAN,DC   |
| 311                                | 4-671-506-01 | GASKET (FAN)   |
| 313                                | 2-190-257-01 | STAND OFF D  |
| 314                                | 2-176-476-01 | HEAT SINK (CPU)  |
| 315                                | 4-668-785-02 | THERMAL SHEET CPU  |
| 317                                | 2-176-466-01 | PLATE GME (MB)   |
| 318                                | 2-176-474-01 | TAPE CAPTON (GME)  |
| 319                                | 1-756-038-21 | BATTERY, NICKEL HYDROGEN   |
| B2                                 | 4-672-834-51 | SCREW,+B EG GRIP   |
| B4                                 |              | GRIP,M2  |
| B5                                 |              | SCREW,+B EG GRIP   |
| B10                                | 4-672-834-31 | SCREW, +B EG GRIP  |

<sup>●1</sup> Use the FILAMENT TAPE



| 1            |          |              |         |                               | J      |        | AM    |        | EU   |      |      |      |       |      |      | $\neg$ |      |          |          |          |
|--------------|----------|--------------|---------|-------------------------------|--------|--------|-------|--------|------|------|------|------|-------|------|------|--------|------|----------|----------|----------|
|              |          |              |         |                               | B90PS* | B100B* | B100* | B150FP | B1XP | B1VP | B3XP | B3VP | B88GP | B88L | B55G | B55S   | B55L | B55T     | B88C     | B55C     |
|              | Ref. No. |              |         | Description                   |        | -      | _     |        | ⊢    |      |      |      |       |      |      | _      |      | $\dashv$ | $\dashv$ | $\dashv$ |
|              | 302      | 6-706-244-01 | <br>    | IC EBD11UD8ADDA-6B(1GB)       |        | •      | •     |        | ļ    | ļ    |      |      | ļ     |      |      |        |      |          |          |          |
|              |          | 6-705-096-01 |         | IC HYS64D64020HBDL-6-C(512MB) |        | •      | •     |        |      |      |      |      |       |      |      |        |      |          |          |          |
| l l          | 305      | A-1090-871-A | \$<br># | COMPLETE PWB MBX-123(M512)    | •      | •      | •     | •      | •    | •    | •    | •    | •     |      |      |        |      |          |          |          |
|              |          | A-1090-872-A | \$<br># | COMPLETE PWB MBX-123(M256)    | •      | •      | •     |        |      |      |      |      |       | •    | •    | •      | •    | •        | •        | •        |
| [            | 306      | 1-761-864-23 | <br>#   | WIRELESS LAN CARD             | •      | L      |       | L      | l    |      |      |      | L     |      |      |        |      |          |          |          |
|              |          | 1-761-864-14 | #       | WIRELESS LAN CARD             |        | •      | •     | •      |      |      |      |      |       |      |      |        |      | •        |          | - 1      |
| [            |          | 1-761-864-33 | <br>#   | WIRELESS LAN CARD             |        |        |       |        | •    | •    |      |      | •     | •    | •    | •      | •    |          | •        | •        |
| <u></u> [MA] |          | 1-761-864-71 | <br>#   | WIRELESS LAN CARD             | 1      | T      | Ī     |        | Ī    |      | •    | •    |       |      |      |        |      |          |          |          |
|              | 316      | 6-600-368-01 |         | IC RH80536GC0212MSL7GL(1.5A)  |        | •      | •     | •      |      |      |      |      | •     | •    | •    | •      | •    | •        | $\neg$   | $\neg$   |
| l l          |          | 6-600-355-01 | <br>    | IC RH80536GC0252MSL7EG(1.6)   | •      | •      | •     |        | 1    | •    |      | •    |       |      |      |        |      |          | •        |          |
| l l          |          | 6-600-343-01 | <br>    | IC RH80536GC0292MSL7EP(1.7)   | 1      | •      | •     |        | •    |      |      |      |       |      |      |        |      |          |          |          |
|              |          | 6-600-306-01 | <br>    | IC RH80536GC0332MSL7EN(1.8)   | •      | •      | •     |        |      |      | •    |      |       |      |      |        |      |          |          |          |
|              |          | 6-706-559-01 | <br>    | IC RH80536GC0412MSL7EM(2.0)   | •      | •      | •     |        |      |      |      |      |       |      |      |        |      |          |          |          |
|              |          | 6-707-262-01 | <br>    | IC RH80536NC0131M(Cel1.3)     | •      | •      | •     |        | ļ    |      |      |      |       |      |      |        |      |          |          | •        |
|              | 320      |              |         | FILAMENT TAPE(19x30) (●1)     | •      | •      | •     | •      | •    | •    | •    | •    | •     | •    | •    | •      | •    | •        | ヿ        | $\neg$   |


- This parts list contains two different types of parts.
  The first type is the parts that are common to all models.
- The other type is the parts that are different depending on each model.
- The parts of Ref.306, 320 are used in the Wireless-LAN installation models.
- ・この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- Ref. 306, 320は、ワイヤレスラン搭載モデル用の部品です。

Confidential

VGN-B90PS (J)

VGN-B100/B100B/B150FP (AM)

VGN-B1VP/B1XP/B3VP/B3XP (EU)



| Ref.No.           | Part No.                  |       | Description                           |
|-------------------|---------------------------|-------|---------------------------------------|
| 28                |                           |       | FILAMENT TAPE(12x30) (●1)             |
| 501               | <del>A-1090-572-A</del>   |       | BASE DISPLAY(HBA)(S)                  |
| 502               | 2-176-449-01              |       | BRACKET DSUB (BTM)                    |
| 503               | A-1090-874-A \$           | 6     | MOUNTED PWB CNX-281(S)                |
| 504               | 1-829-801-11              |       | FLEXIBLE FLAT CABLE (14PIN)           |
| Ê                 | [CHG] 2-176-367           | -11   |                                       |
| 505               | 1-500-227-31              |       | BEAD, FERRITE                         |
| 506               | 2-345-848-01              |       | BRACKET ETHER(BTM)                    |
| 507               | 1-963-259-21              |       | HARNESS, CONNECTOR WITH               |
| 508               | A-1090-873-A \$           | 3     | MOUNTED PWB ANL-55(S)                 |
| 509               | 1-829-800-11              |       | FLEXIBLE FLAT CABLE (12PIN)           |
| A                 | [CHG] 2-176-373           | -11   | ,                                     |
| 510               | <del>- A-1090-578-A</del> |       | BRACKET PR (HBA)(S)                   |
| 511               | A-1090-577-A-             |       | COVER PR (HBA)(S) 2-176-372-11        |
| 512               | X-2023-017-1              |       | HOUSING BOTTOM ASSV (HBA)             |
| 513               | A-1090-573-A-             |       | & FOOT BOTTOM (HBA)(S)                |
| 514               | A-1090-571-A              |       | COVER BATT (HBA)(S)                   |
|                   | [CHG] 2-176-369           | -11 L | (HB/1)(0)                             |
|                   | — <del>A-1090-574-A</del> | • •   | LEVER RELEASE (HBA)(S)                |
| 516               | A-1090-579-A              |       | SPRING RELEASE (HBA)(S)               |
| 517               | A-1090-575-A              |       | VNOD DELEASE (HDAVS)                  |
| 518               | - A-1090-576-A            |       | KNOB LEFT (HBA)(S) (CHG] 2-176-370-11 |
| 519               | 1-961-978-12              |       | HARNESS (WITH DC JACK 2P)             |
|                   | [CHG] 2-176-371           | 11    | THURS (WITH BO GROKET)                |
| 520 <sup>/2</sup> | 2-176-443-01              | - 1 1 | BRACKET DC (BTM)                      |
| 530               | 2-176-439-01              |       | BRACKET (HDD)                         |
| 531               | 2-176-486-01              |       | INSULATOR HDD (HDD)                   |
| 532               | 2-176-440-01              |       | ESCUTCHEON (HDD)                      |
| 544               | 2-176-441-01              |       | BRACKET L (ODD)                       |
| 344               | 2-170-441-01              |       | BRACKET L (ODD)                       |
| 545               | 2-176-442-01              |       | BRACKET R (ODD)                       |
| 546               | A-1090-875-A \$           | 3     | MOUNTED PWB IFX-370                   |
| 547               | 2-176-487-01              |       | INSULATOR ODD (IFX370)                |
| 549               | 4-658-789-02              |       | TAPE(HARNESS)                         |
| 550               | 2-548-222-01              |       | SHEET BD(BTM)                         |
|                   |                           |       |                                       |
| B2                | 4-672-834-51              |       | SCREW,+B EG GRIP                      |
| В3                | 4-672-834-21              | <     | SCREW,+B EG GRIP                      |
| B5                | 4-672-834-91              |       | SCREW,+B EG GRIP                      |
| B7                | 4-674-716-01              |       | SCREW(NO.4-40)(UNC)                   |
| В8                | 4-672-835-01              |       | SCREW, M2.6 +B EG GRIP                |
|                   |                           |       |                                       |
| B10               | 4-672-834-31              | <     | :&> SCREW, +B EG GRIP                 |
| B11               | 4-644-637-61              | <     | - 8> M2 EG GRIP                       |
| B12               | 4-671-538-01              |       | SCREW(M2X4), SPECIAL HEAD             |
| B13               | 4-672-836-01              |       | SCREW ,M2 SPECIAL HEAD,EG GRIP        |
| B16               | 4-682-270-01              |       | SCREW,M2 +B EG GRIP                   |
|                   |                           |       |                                       |
| B17               | 4-671-885-01              |       | SCREW, TAPPING, SPECIAL               |
| B18               | 4-672-839-01              |       | HEAD, M3 FLAT                         |
|                   |                           |       |                                       |
|                   |                           |       |                                       |

<sup>●1</sup> Use the FILAMENT TAPE

|                 |          |                              |   |  | J             |              | AM    |        |               | EU     |      | Т        |        |                 |          | Α       | 0        |          | _    | П          |
|-----------------|----------|------------------------------|---|--|---------------|--------------|-------|--------|---------------|--------|------|----------|--------|-----------------|----------|---------|----------|----------|------|------------|
|                 |          |                              |   |  | B90PS*        | B100B*       | B100* | B150FP | B1XP          | B1VP   | ВЗХР | B3VP     | В88СР  | B88L            | B55G     | B55S    | B55L     | B55T     | B88C | B55C       |
|                 |          | Part No.                     | _ | <br>Description  | $\vdash$      | -            | _     |        | Н             | +      | +    | +        | +      | $\dashv$        |          |         |          | $\dashv$ | +    | $\dashv$   |
|                 | 533      | A-1083-188-A                 |   | <br>HDD (MHU2100AT-100GB) (S)                                    | ļ. <u>.</u> . | •            | •     |        |               |        | +    |          |        |                 |          |         |          |          | +    |            |
|                 |          | A-1068-138-A<br>A-1065-502-A |   | <br>ASSY HDD 80GB (-21) (H,40) (S)                               | •             | •            | •     |        | •             |        | +    |          |        | •               |          |         |          |          |      |            |
|                 |          | A-1065-502-A<br>A-1062-141-A |   | <br>ASSY HDD 60GB (-21) (I,40) (S)<br>HDD (MHT2040AT-40GB-A) (S) |               |              | •     |        | •             | •      | +    |          | •      | •               | •        | •       | •        |          |      |            |
| <b>∱</b> [MA]   | <b></b>  | A-1062-141-A<br>A-1083-186-A |   | <br>HDD (40GB,HTS424040) (S)                                     | -             | -            | •     | •      |               | •      | +    |          | •      |                 | •        | •       | •        | •        |      | _          |
| ZIZ [IVIA]      | <b> </b> | 1-797-045-11                 |   | <br>HDD (30GB,HTS424030M9AT00)                                   | +             | •            | •     |        | <del>  </del> |        | +    | +-       | +      |                 |          |         |          |          |      |            |
| ∕4\ [MA]        | <b> </b> | A-1122-579-A                 |   | <br>ASSY HDD 60GB (-31) (H40) (S)                                | +             | ļ            |       |        | <del>  </del> |        | +    | •        | +      |                 |          |         |          |          | +    |            |
| 4 [MA]          |          | A-1122-578-A                 |   | <br>ASSY HDD 80GB (-31) (H40) (S)                                | +             | <del> </del> |       |        | <del>  </del> |        | -    | +-       |        |                 |          |         |          |          | +    |            |
| 747 [W 1]       | 540      | 1-797-056-11                 |   | W-DVD (DVR-K14VAS)   | •             | •            | •     |        | •             | +      | +    | +        | •      | $\dashv$        | $\dashv$ | -       | $\vdash$ | $\dashv$ | +    | $\dashv$   |
|                 |          | 1-797-060-11                 |   | <br>DVD-ROM DRIVE(SDR-088)                                       | †             | •            | •     |        |               |        |      |          | -+     | +               |          |         |          |          |      |            |
|                 | l        | 1-796-941-12                 |   | <br>COMBO DRIVE (SBW-242C)                                       | •             | •            | •     | •      | ·             | •      | †    |          | +      | •               | •        | •       | •        | •        | •    | •          |
| <b>∕</b> ₄ [MA] | ·        | 1-797-271-11                 |   | <br>UJ840 (DVD+-RW,12.7MM)                                       | †             | t            |       |        |               |        | •    | •        |        |                 |          |         |          |          |      |            |
|                 | 541      | X-2023-023-1                 |   | BEZEL ODDP ASSY (BOPA)   | •             | •            | •     |        | •             | $\neg$ | _    | $\neg$   | •      | $\neg$          |          |         |          | $\neg$   | 十    | ┨          |
|                 | 542      | X-2023-985-1                 |   | BEZEL ODDQ DR ASSY(BOQA)   | T             | •            | •     |        |               | $\neg$ | _    | $\neg$   | $\top$ | _               |          |         |          |          | 1    | $\dashv$   |
|                 | l        | X-2023-024-1                 |   | <br>BEZEL ODDQ ASSY (BOQA)                                       | •             | •            | •     | •      |               | •      |      |          |        | •               | •        | •       | •        | •        | •    | •          |
| <b></b> ₄ [MA]  | 543      | X-2055-859-1                 |   | ASSY BEZEL ODDP DUAL G-BAS                                       |               |              |       |        | П             |        | •    | •        | 1      | $\neg$          |          |         |          |          | T    | コ          |
|                 | 548      | 1-400-255-11                 |   | FERRITE CORE   | •             | •            | •     | •      | •             | •      | •    | •        | •      | •               | •        | •       | •        | •        | T    | ヿ          |
|                 | B14      | 4-676-934-01                 |   | +SPECIAL HEAD SELF SCREW T0.2                                    | •             | •            | •     | •      |               | •      |      |          |        | •               | •        | •       | •        | •        | •    | •          |
|                 | B15      | 4-679-805-11                 |   | SCREW (B1.7), TAPPING  | •             | •            | •     |        | •             |        |      |          | •      |                 |          |         |          |          |      |            |
|                 |          |                              |   |  |               |              |       | [MA]   |               | Z LVVI |      | 4 / [ww] |        | 3\ Z<br>  Yw  : | <u></u>  | <u></u> |          | ₫.<br>WY |      | MA]<br>MA] |

 This parts list contains two different types of parts.
The first type is the parts that are common to all models. The other type is the parts that are different depending on each model.

- The parts of Ref.548 is used in the Wireless-LAN installation models.
- ・この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- Ref. 548は、ワイヤレスラン搭載モデル用の部品です。


Confidential

VGN-B90PS (J)

VGN-B100/B100B/B150FP (AM) VGN-B1VP/B1XP/B3VP/B3XP (EU)

## L-1. LCD 14.1-inch SXGA+

- Made by To -



Confidential

VGN-B90PS (J) VGN-B100/B100B/B150FP (AM) VGN-B1VP/B1XP/B3VP/B3XP (EU)

## L-1. LCD 14.1-inch SXGA+

## - Made by To -

| Ref.No. | Part No.                  |      |    | Description<br>FILAMENT TAPE(12x30) (●1)  |
|---------|---------------------------|------|----|---|
| 1001    | X-2023-027-1              |      |    | HOUSING BEZEL ASSY (HBEA)                 |
| 1001    | A-1090-605-A              | Г    | &  | CUSHION OVAL (HBEA)(S) (CHG] 2-176-459-11 |
| 1002    | A-1090-604-A              |      | X  | , , ,                                     |
|         |                           |      | _  | LEVER LATCH (HBEA)(S) [CHG] 2-176-457-11  |
|         | A-1090-606-A              |      |    | COIL SPRING, COMPRESSION(S)               |
|         | [CHG] 4-671-04            |      | _  |   |
| 1005    | 2-176-460-01              |      | &  | CUSHION CIRCLE (DISPLAY)                  |
| 1006    | A-8114-655-A              | \$ # |    | LCD (UNIT) (14SXGA+) (S)                  |
| 1007    | 2-176-461-01              |      |    | BRACKET SLCDL (DISPLAY)                   |
| 1008    | 2-176-462-01              |      |    | BRACKET SLCDR (DISPLAY)                   |
| 1009    | 1-478-924-11              |      |    | INVERTER UNIT                             |
|         |                           |      |    |   |
| 1010    | 1-963-265-11              |      |    | LCD HARNESS SXGA+ FIX                     |
| 1011    | 4-671-222-01              |      |    | SHEET (LH)                                |
| 1012    | 2-176-469-01              |      |    | HINGE L (DISPLAY)                         |
| 1013    | 2-176-470-01              |      |    | HINGE R (DISPLAY)                         |
| 1016    | A-1090-879-A              | \$   |    | HOUSING DISPLAY ASSY(HAD)(S)              |
| A       | [CHG] 2-176-45            | •    |    |   |
| 1017    | 4-658-789-02              |      |    | TAPE (HARNESS)                            |
| 1019    |                           |      |    | FILAMENT TAPE(19x30) (●1)                 |
| 1020 L  | <del>- A 1090-603-A</del> |      |    | TAPE ADHESIVE (HDA) (S)                   |
| 1020    | 7 1000-000 7              |      |    | TALEADILLOIVE (IIDA) (0)                  |
| B5      | 4-672-834-91              |      |    | SCREW,+B EG GRIP                          |
| B14     | 4-676-934-01              |      |    | +SPECIAL HEAD SELF SCREW T0.2             |
| B19     | 4-672-834-61              |      |    | SCREW, +B EG GRIP                         |
| B20     | 4-672-836-11              | <8   | &> | SCREW ,M2 SPECIAL HEAD,EG GRIP            |
| B19     | 4-672-834-61              | <8   | &> | SCREW, +B EG GRIP                         |

<sup>●1</sup> Use the FILAMENT TAPE



|          |              |                           | J      | Α      | M     | Е    | U    |
|----------|--------------|---------------------------|--------|--------|-------|------|------|
| Ref. No. | Part No.     | Description               | *S4068 | B100B* | B100* | B1XP | B3XP |
| 1014     | 1-754-353-41 | ANTENNA, FILM (FOR LEFT)  | •      | •      | •     | •    | •    |
| 1015     | 1-754-353-31 | ANTENNA, FILM (FOR RIGHT) | •      | •      | •     | •    | •    |
| 1018     |              | FILAMENT TAPE(12x70) (●1) | •      | •      | •     | •    | •    |




- This parts list contains two different types of parts.
   The first type is the parts that are common to all models.
   The other type is the parts that are different depending on each model.
- The parts of Ref.1014, 1015 and Ref.1018 are used in the Wireless-LAN installation models.
- ・この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- Ref. 1014, 1015, 1018は、ワイヤレスラン搭載モデル用の部品です。

Confidential

VGN-B90PS (J)

VGN-B100/B100B/B150FP (AM) VGN-B1VP/B1XP/B3VP/B3XP (EU) - Made by Hi -



Confidential

VGN-B90PS (J) VGN-B100/B100B/B150FP (AM) VGN-B1VP/B1XP/B3VP/B3XP (EU)

## L-2. LCD 14.1-inch XGA


## - Made by Hi-

| Ref.No.       | Part No.           |              | Description                    |
|---------------|--------------------|--------------|--------------------------------|
| 28            |                    |              | FILAMENT TAPE(12x30) (●1)      |
| 1001          | X-2023-027-1       |              | HOUSING BEZEL ASSY (HBEA)      |
| 1002          | A-1090-605-A       | <b>-</b>   & | CUSHION OVAL (HBEA)(S)         |
| 1003          | A-1090-604-A       |              | LEVER LATCH (HBEA)(S)          |
| 1004 <b>г</b> | -A-1090-606-A      |              | COIL SPRING, COMPRESSION(S)    |
| <u> </u>      | [CHG] 4-671-043-21 |              |                                |
| 1005          | 2-176-460-01       | &            | CUSHION CIRCLE (DISPLAY)       |
| 1009          | 1-478-924-11       |              | INVERTER UNIT                  |
| 1011          | 4-671-222-01       |              | SHEET (LH)                     |
| 1012          | 2-176-469-01       |              | HINGE L (DISPLAY)              |
| 1013          | 2-176-470-01       |              | HINGE R (DISPLAY)              |
|               |                    |              |                                |
| 1014          | 1-754-353-41       |              | ANTENNA, FILM (FOR LEFT)       |
| 1015          | 1-754-353-31       |              | ANTENNA, FILM (FOR RIGHT)      |
| 1016          | A-1090-879-A \$    |              | HOUSING DISPLAY ASSY(HAD)(S)   |
| 1017          | 4-658-789-02       |              | TAPE (HARNESS)                 |
| 1018          |                    |              | FILAMENT TAPE(12x70) (●1)      |
| 2             | [CHG] 2-176-454-11 |              |                                |
| 1019          | -                  |              | FILAMENT TAPE(19x30) (●1)      |
| 1020 L        | -A-1090-603-A      |              | TAPE ADHESIVE (HDA) (S)        |
| 1101          | 2-177-770-01       |              | BRACKET X HLCDL (DISPLAY)      |
| 1102          | 2-177-771-01       |              | BRACKET X HLCDR (DISPLAY)      |
| 1103          | 1-963-266-11       |              | LCD HARNESS XGA FIS            |
|               |                    |              |                                |
| 1104          | A-8113-928-A \$ #  |              | LCD UNIT(14.1XGA)(H)(S)        |
|               |                    |              |                                |
| B5            | 4-672-834-91       |              | SCREW,+B EG GRIP               |
| B14           | 4-676-934-01       |              | +SPECIAL HEAD SELF SCREW T0.2  |
| B19           | 4-672-834-61       |              | SCREW, +B EG GRIP              |
| B20           | 4-672-836-11       | <&>          | SCREW ,M2 SPECIAL HEAD,EG GRIP |
|               |                    |              | ·                              |

●1 Use the FILAMENT TAPE

Confidential

VGN-B90PS (J) VGN-B100/B100B/B150FP (AM) VGN-B1VP/B1XP/B3VP/B3XP (EU)



Confidential

VGN-B90PS (J) VGN-B100/B100B/B150FP (AM) VGN-B1VP/B1XP/B3VP/B3XP (EU)

## L-3. LCD 14.1-inch XGA - Made by CPT-

| Ref.No.<br>28<br>1001<br>1002<br>1003<br>1004 | X-2023-027-1 A-1090-605-A A-1090-606-A                       | J <sub>&amp;</sub> | CUSHION OVAL (HBEA)(S)   | <u> </u> |
|---|--|--------------------|--|----------|
| <u>/2</u><br>1005                             | [CHG] 4-671-043-21<br>2-176-460-01                           | &                  | CUSHION CIRCLE (DISPLAY)   |          |
|   | 1-478-924-11<br>4-671-222-01                                 |                    | INVERTER UNIT<br>SHEET (LH)  |          |
| 1013  |  |                    | HINGE L (DISPLAY)<br>HINGE R (DISPLAY)   |          |
| 1016<br>1017<br>1019<br>1020                  | A-1090-879-A \$ 4-658-789-02                                 |                    | HOUSING DISPLAY ASSY(HAD)(S) TAPE (HARNESS) FILAMENT TAPE(19x30) (●1) TAPE ADHESIVE (HDA) (S) BRACKET X LCDL (DISPLAY) |          |
| 1202<br>1203<br>1204                          | 2-176-464-01<br>1-963-264-11<br>A-1090-877-A \$ #            |                    | BRACKET X LCDR (DISPLAY)<br>LCD HARNESS XGA FIX<br>LCD UNIT 14.1XGA CLAA141XD(S)                                       |          |
| B5<br>B14<br>B19<br>B20                       | 4-672-834-91<br>4-676-934-01<br>4-672-834-61<br>4-672-836-11 | <&>                | SCREW,+B EG GRIP<br>+SPECIAL HEAD SELF SCREW T0.2<br>SCREW, +B EG GRIP<br>• SCREW ,M2 SPECIAL HEAD,EG GRI              |          |

<sup>●1</sup> Use the FILAMENT TAPE

|          |              |                           | Al     | M     |       | AO   |      |      |      |      |  |  |  |
|----------|--------------|---------------------------|--------|-------|-------|------|------|------|------|------|--|--|--|
|          |              |                           | B100B* | B100* | B88GP | B88L | B55G | B55S | B55L | B55T |  |  |  |
| Ref. No. | Part No.     | Description               |        |       |       |      |      |      |      |      |  |  |  |
| 1014     | 1-754-353-41 | ANTENNA, FILM (FOR LEFT)  | •      | •     | •     | •    | •    | •    | •    | •    |  |  |  |
| 1015     | 1-754-353-31 | ANTENNA, FILM (FOR RIGHT) | •      | •     | •     | •    | •    | •    | •    | •    |  |  |  |
| 1018     | <del></del>  | FILAMENT TAPE(12x70) (I1) | •      | •     | •     | •    | •    | •    | •    | •    |  |  |  |

- This parts list contains two different types of parts. The first type is the parts that are common to all models. The other type is the parts that are different depending on each model.

  The parts of Ref.1014, 1015 and Ref.1018 are used in the Wireless-LAN installation models.

  この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。

- Ref. 1014, 1015, 1018は、ワイヤレスラン搭載モデル用の部品です。

Confidential

VGN-B90PS (J)

VGN-B100/B100B/B150FP (AM) VGN-B1VP/B1XP/B3VP/B3XP (EU)

## A-1. Accessories




























|            |          |                              |              |   | J       | +       | AM       |              |      | E    | U           |      | AO    |           |           |          |          |               |      | _  |
|------------|----------|------------------------------|--------------|---|---------|---------|----------|--------------|------|------|-------------|------|-------|-----------|-----------|----------|----------|---------------|------|----|
|            | Ref. No. | Part No.                     |              | Description                               | *SOOPS* | B100B*  | B100*    | B150FP       | B1XP | B1VP | B3XP        | B3VP | B88GP | B88L      | B55G      | B55S     | B55L     | B55T          | B88C |    |
| ı          | 2001     | 1-478-860-21 \$              | &            | ADAPTOR,AC                                | •       | •       | •        | •            | •    | •    |             |      | •     | •         | •         | •        | •        | •             | •    | 1  |
| MA]        |          | 1-478-860-31 \$              | &            | ADAPTOR, AC                               |         |         | 1        | 1            |      |      | •           | •    |       |           |           |          | ļ        |               |      | T  |
|            | 2002     | A-8114-136-A \$              | &            | BP2V(J)ASSY(S)                            | •       | )       |          |              |      |      |             |      |       |           |           |          |          |               |      | T  |
| [          |          | A-8114-137-A \$              | &            | BP2V(U)ASSY(S)                            |         | •       | •        |              |      |      |             |      |       |           |           |          | Ī        |               |      | Γ  |
|            |          | 1-756-328-23 \$              | &            | BATTERY PACK, LITHIUM ION(PCGA            |         |         | T        | •            | •    | •    | •           | •    | •     | •         | •         | •        | •        | •             | •    | Γ  |
| [MA]       | 2003     | 1-555-074-32                 | &            | CORD, POWER                               |         |         |          |              |      |      |             |      | •     |           | •         |          |          |               |      | Γ  |
| l l        | 2004     | 1-829-237-21                 | &            | CORD, POWER                               |         | •       | •        | •            |      |      |             |      |       |           |           |          |          | •             |      | L  |
| MA]        | 2005     | 1-782-476-22                 | &            | CORD, POWER                               |         |         |          | ļ            |      |      | ļ           |      |       |           |           |          | ļ        | L             | •    | ļ. |
| - [        |          | 1-790-732-32                 | &            | CORD, POWER                               | •       | 1       |          |              |      |      |             |      |       |           |           |          |          |               |      | L  |
| [MA]       | 2006     | 1-823-935-51                 | &            | CORD, AC POWER                            |         | $\perp$ |          |              |      |      |             |      | •     |           | •         |          |          |               |      | L  |
| [MA]       | 2007     | 1-823-947-32                 | &            | POWER-SUPPLY CORD                         |         | +       | _        | _            | _    |      | _           |      |       | •         |           | _        | •        | Ш             |      | ╀  |
|            | 2008     | 1-827-481-21<br>1-770-019-51 | &<br>&       | POWER-SUPPLY CORD                         |         | +       | +        |              | •    | •    | •           | •    |       |           |           | •        |          | Ш             |      | Ļ  |
|            | 2009     | 1-770-019-51                 | - &<br>&     | ADAPTOR, CONVERSION PLUG<br>CORD, POWER   | _       | +       | +-       |              | •    | •    | •           | •    |       |           |           |          | _        | Н             |      | ╀  |
| MA]        | 2010     | 1-816-429-12                 | <u>«</u>     | PHONE PLUG (GB)                           |         |         | -+       |              | •    |      | •           |      |       |           |           |          |          |               |      | ł. |
| ŀ          |          | 2-318-389-01                 | <u>&amp;</u> | MANUAL (XP), INSTRUCTION                  |         |         | -+       | <del> </del> |      |      |             |      |       |           |           |          |          |               |      | ŀ  |
| H          |          | 2-547-802-01                 | <u>&amp;</u> | WELCOME MAT(U)                            |         | •       | -        | <del> </del> |      |      |             |      |       |           |           |          |          |               |      | t  |
| [MA]       |          | 2-541-892-01                 | - &          | WELCOME MAT(D)                            | _       | Ť       | Ť        | •            | _    |      | $\vdash$    |      |       |           |           |          | $\vdash$ | Н             |      | t  |
| LIVII (J   |          | 2-345-490-01                 | - &          | GETTING STARTED,E                         | _       | +       | +        | Ť            | •    | •    |             |      |       |           |           |          | $\vdash$ | Н             |      | t  |
| ŀ          |          | 2-345-489-01                 | - &          | HW SPECS,E(GB)                            |         | +       | +        |              | •    | •    |             |      |       |           |           |          |          | Н             |      | t  |
| - 1        |          | 2-345-489-11                 | &            | HW SPECS,E(DE)                            |         |         | +        | <del> </del> | •    | •    |             |      |       |           |           |          |          |               |      | t  |
| - 1        | -        | 2-345-489-21                 | &            | HW SPECS,E(FR)                            |         |         | +        | †            | •    | •    |             |      |       |           |           |          |          |               |      | t  |
| - 1        | -        | 2-345-489-31                 | &            | HW SPECS,E(IT)                            |         |         | †        |              | •    | •    |             |      |       |           |           |          |          |               |      | t  |
| ı          | -        | 2-345-489-41                 | &            | HW SPECS,E(ES)                            |         |         | †        | ļ            | •    | •    |             |      |       |           |           |          |          |               |      | t  |
| ı          | -        | 2-345-489-51                 | &            | HW SPECS,E(NL)                            |         |         | 1        | ļ            | •    | •    |             |      |       |           |           |          |          |               |      | ľ  |
|            | -        | 2-345-489-61                 | &            | HW SPECS,E(PT)                            |         |         | Ι        |              | •    | •    |             |      |       |           |           |          |          |               |      | [  |
| MA]        | -        | 2-629-979-11                 | &            | (Engkish, German, French, Italian)HW SPEC |         |         | Ι        |              |      |      | •           |      |       |           |           |          |          |               |      | Γ  |
| MA]        | -        | 2-629-979-21                 | &            | (Engkish, German, French, Italian)HW SPEC |         |         |          | ļ            |      |      | •           | •    |       |           |           |          | ļ        | L             |      | ļ. |
| MA]        | -        | 2-629-979-31                 | &            | (Engkish, German, French, Italian)HW SPEC | S       |         |          | ļ            |      |      | •           | •    |       |           |           |          | ļ        | L             |      | Į. |
| MA]        | -        | 2-629-979-41                 | &            | (Italian)HW SPECS                         |         |         |          | ļ            |      |      | •           | •    |       |           |           |          | ļ        | L             |      | ļ. |
| MA]        |          | 2-629-979-51                 | &            | (Spanish)HW SPECS                         |         |         | .4       | ļ            |      |      | ļ. <u>.</u> | •    |       |           |           | ļ        | ļ        | ļļ            |      | ļ. |
| MA]        |          | 2-629-979-61                 | &            | (English)HW SPECS                         |         |         |          |              |      |      | •           | •    |       |           |           |          | ļ        |               |      | ļ. |
| MA]        |          | 2-629-979-71<br>2-629-979-81 | &<br>&       | (English)HW SPECS<br>(English)HW SPECS    |         |         |          | ļ            |      |      | ļ           | •    |       |           |           |          | ļ        |               |      | ļ. |
| MA]        |          | 2-629-979-81                 | <u>«</u>     | (English)HW SPECS                         |         |         | -+       |              |      |      |             |      |       |           |           |          |          |               |      | ł. |
| MA]<br>MA] |          | 2-629-980-11                 | <u>&amp;</u> | (English)HW SPECS                         |         |         | -+       | <del> </del> |      |      |             | -    |       |           |           |          |          |               |      | ╁  |
| MA]        |          | 2-629-980-21                 | <u>&amp;</u> | (English)HW SPECS                         |         |         | -+       | <del> </del> |      |      |             |      |       |           |           |          |          | <del>  </del> |      | ŀ  |
| [MA]       |          | 2-320-681-11                 | - &          | SPEC SHEET                                | _       | +       | +        |              | _    |      |             | _    | •     |           | •         | •        |          | Н             |      | t  |
| [MA]       | -        | 2-320-681-21                 | &            | SPEC SHEET                                |         | +       | +        | <del> </del> |      |      |             |      |       | •         |           |          | •        |               |      | t  |
| [MA]       | -        | 2-320-682-31                 | &            | SPEC SHEET                                |         | +       | +        | †            |      |      | ·           |      |       |           |           |          | †        |               | •    | t  |
| [MA]       | -        | 2-320-681-41                 | &            | SPEC SHEET                                |         | +       | †        | †            |      |      | ·           |      |       |           |           |          | †        | •             |      | t  |
| [MA]       | -        | 2-320-668-11                 | &            | SAFETY/REGURATIONS GUIDE                  |         | 1       |          |              |      |      |             |      | •     |           | •         | •        |          | П             |      | T  |
| [MA]       |          | 2-320-668-21                 | &            | SAFETY/REGURATIONS GUIDE                  |         | 1       | Ι        | Ι            |      |      | [           |      |       | •         |           |          | •        |               |      | ľ  |
| [MA]       | -        | 2-320-668-41                 | &            | SAFETY/REGURATIONS GUIDE                  |         | 1       | <u> </u> |              |      |      |             |      |       |           |           | L        | L        | •             |      | Γ  |
| [MA]       | -        | 2-320-669-11                 | &            | TROUBLESHOOTING GUIDE                     |         |         |          |              |      |      |             |      | •     |           | •         | •        |          |               |      | Γ  |
| [MA]       | -        | 2-320-669-21                 | &            | TROUBLESHOOTING GUIDE                     |         |         |          | ļ            |      |      | ļ           | L]   |       | •         |           |          | •        | LII           |      | Ĺ  |
| [MA]       | -        | 2-320-669-41                 | &            | TROUBLESHOOTING GUIDE                     |         |         |          |              | _    |      |             |      |       |           |           |          |          | •             |      | L  |
| MA]        | -        | 2-632-233-01                 | &            | REGULATORY BOOKLET(JDS)                   |         |         |          |              |      |      | •           | •    |       |           |           |          |          |               |      | L  |
|            |          |                              |              |   |         |         |          | [MA]         |      | _    | 4           | 4    | 3     | <u> 3</u> | <u> 3</u> | <u> </u> | 3        | [MA]          | 1    | 2  |
|            |          |                              |              | ifferent types of parts.                  |         |         |          |              |      |      | MA.         | MA]  |       |           |           |          | _        | _ ~           | _    | -  |

This parts list contains two different types of parts.
 The first type is the parts that are common to all models.
 The other type is the parts that are different depending on each model.
 この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。

Confidential

VGN-B90PS (J)

VGN-B100/B100B/B150FP (AM) VGN-B1VP/B1XP/B3VP/B3XP (EU)

VGN-B55C/B55G/B55L/B55S/B55T/B88C/B88GP/B88L (AO)


4-14 (END)


# CHAPTER 5. OTHERS

## 5-1. The Barcode Label

The hatched portion of the barcode label is used as the repair data.

バーコードラベルの網掛け部は、修理データとして使用いたします。






## Confidential

- VGN-B90PS (J)
- VGN-B100/B100B/B150FP (AM)
- VGN-B1VP/B1XP/B3VP/B3XP (EU)

## 5-2. Replacing the CPU


#### 1. How to remove the CPU

1) Rotate the lock with a flat-blade screwdriver toward



#### 2. How to install the CPU

① Position the mark on the CPU to the mark on the CPU socket and put in all pins to the holes on the CPU socket.



Note: Lock the CPU properly, or operation becomes unstable.

Confidential

VGN-B90PS (J)

VGN-B100/B100B/B150FP (AM)

VGN-B1VP/B1XP/B3VP/B3XP (EU)



List of VGN-B Series (As of April, 2005)

| Service Manual | Model Name |            |             |           |  |  |  |  |  |  |  |  |  |
|----------------|------------|------------|-------------|-----------|--|--|--|--|--|--|--|--|--|
| Parts No.      | J          | AM         | EU          | AO        |  |  |  |  |  |  |  |  |  |
|                | VGN-B90PS* | VGN-B100B* | VGN-B1XP    | VGN-B88GP |  |  |  |  |  |  |  |  |  |
|                |            | VGN-B100*  | VGN-B1VP    | VGN-B55G  |  |  |  |  |  |  |  |  |  |
|                |            | VGN-B150FP | VGN-B3XP ~~ | VGN-B88L  |  |  |  |  |  |  |  |  |  |
| 9-876-389-xx   |            |            | VGN-B3VP ~  | VGN-B55L  |  |  |  |  |  |  |  |  |  |
| 9-070-309-88   |            |            |             | VGN-B88C  |  |  |  |  |  |  |  |  |  |
|                |            |            |             | VGN-B55C  |  |  |  |  |  |  |  |  |  |
|                |            |            |             | VGN-B55T  |  |  |  |  |  |  |  |  |  |
|                |            |            |             | VGN-B55S  |  |  |  |  |  |  |  |  |  |
|                |            | VGN-B250FP |             | VGN-B99GP |  |  |  |  |  |  |  |  |  |
|                |            |            |             | VGN-B66GP |  |  |  |  |  |  |  |  |  |
| 9-876-407-xx   |            |            |             | VGN-B99C  |  |  |  |  |  |  |  |  |  |
|                |            |            |             | VGN-B66TP |  |  |  |  |  |  |  |  |  |
|                |            |            |             | VGN-B66SP |  |  |  |  |  |  |  |  |  |

\*: CTO model

: Additional Model

This manual and the constituent data may not be replicated, copied nor reprinted in whole or in part without prior written authorization of Sony Corporation.

本マニュアルの一部、または全部について、無断で データの複製、複写、転載することを禁じます。

> English / Japanese 2005D2700-1 © 2005 Sony Corporation

## **Revision History**

| Suffix   | Ver.   | Date       | Contents  | QM No.      |
|--|--------|------------|---|-------------|
| -01  | Ver. 1 | 2004.09.27 | First Edition   |             |
| -02  | Ver. 2 | 2004.10.08 | ⚠ Front Page (Model Lineup), Page 1-1, Page 4-1, Page 4-3, Page 4-5, Page 4-7, Page 4-14, | N2004_103AK |
|  |        |            | Back Cover  |             |
| -03  | Ver. 3 | 2004.10.25 | ♠ Front Page, Page 4-3, Page 4-7, Page 4-9, Page 4-11, Page 4-13, Back Cover              | N2004_114CK |
| -04  | Ver. 4 | 2004.11.05 |   | N2004_123AK |
|  |        |            | Page 4-14, Back Cover   |             |
| -05  | Ver. 5 | 2005.04.28 | ⚠ Front Page (Model Lineup), Page 1-1, Page 4-1, Page 4-3, Page 4-5, Page 4-6, Page 4-7,  | N2005_003AK |
|  |        |            | Page4-9, Page 4-14, Back Cover  |             |
|  |        |            |   |             |
|  |        |            |   |             |
|  |        |            |   |             |
|  |        |            |   |             |
|  |        |            |   |             |
|  |        |            |   |             |
|  |        |            |   |             |
|  |        |            |   |             |
|  |        |            |   |             |
|  |        |            |   |             |
|  |        |            |   |             |
|  |        |            |   |             |
|  |        |            |   |             |
|  |        |            |   |             |
|  |        |            |   |             |
| <remar< td=""><td>rks&gt;</td><td></td><td></td><td></td></remar<> | rks>   |            |   |             |
|  |        |            |   |             |
|  |        |            |   |             |

125